ENDING HOURS:

| | | ENDING HOURS: |
|--|-------|---------------------|
| | | START HOURS: |
| DAILY MAINTENANCE 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 | 1 1 2 | 2 2 2 2 2 2 2 2 3 3 |
| | 4 | |
| CHECK HYDRAULIC OIL LEVEL | | |
| CHECK BLADE: (SHARP/ANGLE) | | |
| GREASE BOTTOM VERT. BEARING | | |
| BRIEF "WALK AROUND" INSPECTION | | |
| | | |
| WEEKLY MAINTENANCE DATES | | NOTES |
| CDEASE HODIZ AND VEDE ALICED DEADINGS | | |
| GREASE LIFT BAR PINS AND BOLTS | | |
| GREASE FOOT PEDAL: BRAKE PEDAL (UNDER DRIVER PLATFORM) | | |
| GREASE BLADE ADJUSTING UNIVERSAL | | |
| CHECK TIRE PRESSURE (80 P.S.I.) | | |
| CLEAN WASH WATER SCREEN | | |
| INSPECT AND REPLACE ELECTROLYTE TO CORRECT LEVEL, WITHIN 1 HR. AFTER | | |
| FULL CHARGE (1/2" ABOVE THE PLATES) | | |
| TEST OPEN CIRCUIT VOLTAGE FOR THE ENTIRE BATTERY PACKAGE | | |
| CHECK SPECIFIC GRAVITY OF FIVE CELLS PER BATTERY TRAY | | |
| MONTHLY AND SEMI-ANNUAL MAINTENANCE | | |
| CHECK POWER CABLES | | |
| GREASE STEERING LINKAGE, DRIVE SHAFT UNIVERSAL, DUMP TANK CYLINDERS, PIVOT PINS | | |
| GREASE DRIVE SHAFT SLIP JOINTS | | |
| CHECK OIL LEVEL IN: DIFFERENTIALS, TRANSFER CASE | | |
| CHECK BELT ADJUSTMENT: VERTICAL AUGER (3/16"), HYD. DRIVE (1/8"), WASH WATER (7/32") | | |
| LUBRICATE HINGES ON ELECTRICAL ENCLOSURE BOYES | | |
| SEMI-ANNUAL: 1ST HYD. FILTER CHANGE AT 50 HRS., SUBSEQUENT CHANGES EVERY 250 HRS. | | |
| CHECK HYD. HOSES, WATER HOSES, AND ELECTRICAL WIRING FOR WEAR. | | |
| | | |